ASSEMBLY INSTRUCTION

H08-HK-005A Ax2 Bx2 x2 9 1 3 x2 Rip it from here Cx2 Dx2 Hx8 Gx2 Ex2 Fx2 Ex2 Wait 72 hours for rebound Insert parts(F)and(G)into the marked position. x2 8 4 <u>(6)</u> x2 10 Dx2 Gx2 Hx8 Jx1 Ix8 Ex2 Ix8 Jx1 All screws in this step need to be 100% M5*10 tightened.