



Item NO.	Dimensions	Capacity	Power(AC/DC adaptor)
	long*wide*high(cm)		
01	Ø 30.5x56.5cm ± 1cm	30L	4x size D batteries
02	Ø 30.5x76.5cm ± 1cm	42L	4x size D batteries
03	Ø 30.5x86.5cm ± 1cm	50L	4x size D batteries

## Safety Cautions

※ Before use, please carefully read the safety checkpoints

### Related signs

※ The safety caution checkpoints intend to avoid unnecessary damage to you and others, and are important for safety. Please abide by them.



Caution

Injury may be caused or the dustbin may break down by mistake in operation



Caution

⊘ This product contains electric and electronic components, and can not be flushed with water, but it may be wiped by wet wipers on its surface

⊘ Avoid direct casting of sunshine on the induction receiver window

⊘ During the open-up process of the cover, don't press the cover with force

⚠ When battery is going to run out, please replace with new ones


⊘ Don't place anything on the dustbin cover

## Product Introduction

Most dustbins with cover for sale in the market need your hand or foot to press on it. This new infrared induction dustbin doesn't need you to contact the dustbin in using it. The cover will automatically open and close, so very clean to use in hospital, working place, household. When a hand or an object approaches its feeder(induction window) at 15-25cm±5cm distance over it, the cover will open automatically and after you drop the trash in it will close automatically. The product adopts photoelectric technique and has stable performance and long life, and low power consumption.

## Parts

● Appearance



## Operation Instruction

- (1) Open the battery cover at bottom of the dustbin, and mound 4 #D batteries according to the correct polarity, and close the battery cover
- (2) Turn on the power switch on the rear of the dustbin, and the indicator turns red (for 3 seconds approx.), and afterwards the indicator will blink every 3 seconds, meaning the electric circuit is in normal status
- (3) When you want to toss a trash in, just let your hand or the object approach the induction window at 15-25cm±5cm distance over it, and keep for 0.5 second, then the cover opens up and it automatically closes in 3 seconds. If your hand or object stays in the induction area, the cover will keep open.
- (4) When the dustbin is full, press "open" button at the induction window (manual open-cover button), and the cover opens up but it will not close. This feature is for use when you frequently put trash in and take trash out. To close the cover just press "lose" button, and there after the circuit resumes its automatic induction function.
- (5) When it is idle, the indicator blinks in red (every 3 seconds)  
When the cover is open, the indicator is green; When the cover is closing, the indicator is red; And when you use manual open-cover function, the indicator blinks in green (every 3 seconds).
- (6) When battery is going to run out, the indicator blinks in yellow (every 3 seconds), and if the dustbin opens and closes for 20 rounds per day, the battery can serve 3 months.