


Resin Garden Shed

OWNER'S MANUAL Instructions for Assembly

SLD-P84-W2



2024-07-16

Requires three people and take 3-4 hours for installation.
Quick & Easy assembly. Ridge Reinforced Walls.
Available in Various Sizes.

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.

Assembly instructions

Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin. During assembly, follow the step sequence carefully for correct results .Please be aware: **this unit takes two people about one full day to complete.**











Parts

Check to be sure that you have all the necessary parts for the building.

Separate contents of the carton by the part number while reviewing parts list.


Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS MAY REQUIRED



Use heavy duty gloves when handling steel sheets and flashing

PLAN AHEAD



Watch the weather:

Please be sure the day you select for installation is dry and calm.

DO NOT attempt to assemble your shed in windy weather because of risk of damage to panels, or personal injury. Be careful of wet or muddy ground.

Teamwork:

Whenever possible, two or more people should work together to assemble the building. One person can position parts or panels

PLAN AHEAD

Site Selection

- Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.
- Small trees,bushes or fences nearby can be helpful,acting as a wind break.

If a concrete pad is made,it is important that this slopes towards the edges to prevent water ingress.
Time must be allowed for any concrete or cement to dry before building the shed on top.

Site Preparation

































The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete,in order to stop the moisture getting into the shed.**The shed is not designed to be built onto lawn directly.**Also the ground will get muddy during rainy days.






Bases can also be constructed from bricks,blocks,or mounted on a concrete pad.
The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.








IMPORTANT NOTES:

- Find someone to help you:it is much easier with someone to hold parts,pass tools ect.Also some steps require two people to lift structures together.This is not very heavy work so would suit most able-bodied people.
- Allow plenty of time:rushing often causes errors and the re-doing of incorrect assemblies.If you have never built a shed before,it can take most of a day to carefully complete the construction.
- Have the right tools to hand.
- Safety clothing as recommended in the 'Tools' section.
- Ideally lat out the parts and check that all are present before commencing construction.Lay on cloths or plastic sheets if there is any risk of scratching the parts.
- Tighten all nuts carefully,being sure not to miss any.Check the frame is square and using a spirit level to check that it is upright.

P84-C01		x 1	P84-C07		x 1	P84-C15		x 4	P84-C21		x 2
P84-C02		x 6	P84-C08		x 3	P84-C16		x 2	P84-C22		x 2
P84-C03		x 1	P84-C09		x 8	P84-C15-1		x 4	F35-C24		x 1
F35-C03		x 1	P84-C10		x 2	P84-C16-1		x 2	P84-C23		x 1
F35-C04		x 3	P84-C11		x 2	P84-C17		x 1	P84-C24		x 1
P84-C04		x 2	P84-C12		x 4	P84-C18		x 1	F35-C27		x 3
P84-C05		x 2	P84-C13		x 2	P84-C19		x 4	F35-C28		x 1
P84-C06		x 2	P84-C14		x 1	P84-C20		x 1	F35-C29		x 4


F35-C30		x 4	F35-A01		x 1			
A64-C30		x 2	F35-A02		x 1			
A64-C31		x 2	C35-A06		x 2			
F35-C31		x 2	F35-A03		x 1			
F35-C32		x 2	P84-A01		x 2			
F35-C33		x 2	AM86-A10		x 2			
C35-A01		x 1	A64-A15		x 2			
C35-A03		x 1	F35-D02		x 1			

E01		x 20					
E02		x 260					
E03		x 32					
E04		x 6					
E12		x 12					




G


G




P84-C01 x1



P84-C02 x3





P84-C03 x1




(ST4.2x12)
E02x8


Pre-installed Basement

A






P84-C10 x2



P84-C09 x6




(ST4.2x12)
E02x12

Pre-installed Back wall




B


I



x2



II








Pre-installed Front wall




C







Pre-installed Side wall

D






P84-C08 x3




(ST4.2x12)
E02x4


Pre-installed Side wall

E




II






F35-C04 x3




F35-C03 x1




C35-A03 x1




F35-A03 x1




C35-A06 x2




F35-C29 x4




A64-A15 x2



(ST4.2x12)
E02x8



(M4x10)
E12x6





(ST4.2x13)
E01x16


Pre-installed Door

F


I




II




III




IV







P84-C04 x2



P84-C05 x2




P84-C06 x2



(ST4.2x12)
E02x8



Pre-installed Roof

G





x2

II




100%







A



F35-C24 x1




P84-C18 x1




P84-C20 x1


I




II




Please use rubber-knife to helping assembly.




P84-C19 x4




F35-C27 x3



F35-C28 x1





A64-C30 x2





(ST4.2x12)
E02x12


I




II




Please use rubber-knife to helping assembly.









B x1




D x1




P84-C21 x1









B x1




C x1









P84-C22 x1




(ST4.2x12)
E02x8









B x1




P84-C21 x1




P84-C23 x1









C x1




E x1




(ST4.2x12)
E02x14









P84-C22 x1




P84-C24 x1




(ST4.2x12)
E02x18







Please use rubber-knife to helping assembly.




C35-A01 x1




F35-A01 x1









P84-C07 x1







F35-A02 x1









(ST4.2x12)
E02x7






(ST4.2x12)
E02x7










P84-C15 x4




P84-C16 x2



(ST4.2x12)
E02x24









G x2






P84-C17 x1




(ST4.2x12)
E02x6




P84-C17



P84-C17



E02











P84-C15-1 x4




P84-C16-1 x2









F35-C30 x4




A64-C31 x2







(ST4.2x12)
E02x18






(ST4.2x12)
E02x24







F x2





(M4x10)
E12x6




ATTENTION!!

When the door is not vertical or parallel after installation, please make appropriate adjustments according to the following figure.








F35-D02 x1




(ST4.2x12)
E01x4










P84-A01 x2



(ST4.2x12)
E02x16



Internal Side View







(ST4.2x12)
E02x22

Internal Side View









AM86-A10 x2




(ST4.2x12)
E02x8







Internal Side View





(ST4.8x19)
E03x32





E04x6

