♠ Warning!


- 1. The toy may have potentially sharp edges or sharp points or small parts prior to assembly, so it must be assembled by an adult.
- 2. Use The car properly under adult supervision or risk injury to yourself or a third party.
- 3. Do not drive or play in dangerous places such as public streets, roads, slopes, swimming pools, etc. . Otherwise, it may cause traffic accident and drowning.
- 4. This toy car may have small parts falling off during use, so it is not suitable for children under to 36 months of age.
- 5. This product is only suitable for children aged 37–96 months. Please put on protective equipment before use, such as helmet, hand protective cover, kneepad, etc. .
- 6. The car can not be overloaded with a maximum load of 30KG.
- 7. chargers and batteries, wires, plugs and other components must be checked regularly for damage and should be stopped from being used until they are repaired.
- 8. Stay away from fire.
- 9. It is important to read the product instructions carefully before doing so and keep them for future reference.
- 10. Two batteries of size 7 are used in the remote control. The batteries must be placed in the correct polarity position.

Electric four-wheeler for children

Installation and operation manual

Age: 37-96 months for children to use

- Cell phone remote control
- Swing back and forth
- Led searchlight
- Open both doors
- 2.4 G ONE ON ONE R/C
- Simulated suspension



Please take good care of the important information in it

Thank you for choosing our electric baby carriage

Please read the manual before using this product, it will tell you the correct operation method and installation steps. To avoid incorrect operation of the product and damage or injury to your baby. This manual shall be properly kept and kept in an accessible place.

Specifications

Storage battery	Large Battery (12V7A battery * 1)	
Motor	Four-wheel drive 12V (380 motor * 4)	
Applicable Age	For children aged 37–96 months	
Maximum load	30kg	
Dimensions	117*75*78CM	
Speed	3.5km/h	
Net weight	19.5kg	
Usage time	Charge for 10–12 hours. Use for 1–2 hours	

Charging points

- 1. When using an electric car for the first time, the battery must be fully charged for 16 hours! Otherwise the battery will be permanently damaged and beyond repair. The charging timeshould not exceed 18 hours.

 2. When charging, first plug the charger DC into the charging socket, and then plug the charger into the power socket.

 3. Each continuous use of 1 hour, you must be timely charging, normal charging time for 10–12 hours.

- 4. Charging process charger or battery heating phenomenon (below 600C) is normal. 5. When the electric baby carriage is not in use for a long time, it must be
- recharged at least once a month.

Battery instruction for Remote Control


- 1. When installing the battery, first open the battery cover, then install the battery according to the polarity, lock the battery cover. In the same way, take out the battery.

 2. The remote control uses 2 # 7 batteries.

 3. The non-rechargeable battery can not be
- charged.
- 4. rechargeable batteries can only be charged under adult supervision.
- from the toy before recharging.

 6. Different types of batteries or old and new batteries should not be mixed.


 7. Batteries should be placed at the correct polarity.
- 8. The depleted battery should be removed from the toy.
- 9. The power terminal must not be short-circuited.



Trouble shooting

Fault type	Detection site	Method of elimination
The Motor won't run	I. Is the foot switch in good contact? I. Is the welding wire on the motor terminal in good condition? I. Is the connector of the motor lead plugged in well? I. Will the motor plug—in disconnect, directly, connected to the battery rotation?	No, fix the foot switch; yes, next. No, weld the terminals to the wire; yes, next. No, plug the connector in; yes, next. Do not turn, change the motor; turn, Drive Circuit Board failure, send professional repair point repair.
To go only forward without going back, or to go only backward without going forward	Detect reverse switch, with a three-meter test, good contact? Drive line to reverse switch wiring, is it good?	No, change the reversing switch; yes, next. No, the line connected; yes, Drive Circuit Board failure, send professional repair point repair.
It's slow	1. Check if the BATTERY VOLTAGE IS ABOVE 12V? 2. Will the motor (with gearbox) directly connected to the battery, speed up or not? 3. Unload the gear box, check the gear rotation, move well or not?	No, charge.—yes, next. No, next item; yes, Drive Circuit Board failure, send professional repair point repair. No, change the gear box; yes, change the motor.
It's not charging	1. Does the charger output terminal have 12V voltage? 2. Will charger input, output plug good, will the battery end two plug springs pull out, test has 12V voltage? 3. Check that the charging seat fastener is loose and the solder joint is free?	No, change the charger, yes, next. Yes, change the battery. No, next. Yeah, plug in the charger.

Circuit Diagram




Instructions

1: Install the rear axle,
take the rear axle and insert
it directly into the corresponding
position on the rear of the
car body


2: Install the front and rear wheels, put the wheel and gasket on the left and right front axle in turn, fix them with nuts, and fasten the

wheel cover.




3: Connect the power, open the battery box under the seat, remove the plastic cap on the battery socket,


point the red socket to the red plug on the battery, insert the total power has been connected. Make sure the music and lights are working properly.





4: The installation of the front bumper, take the front bumper directly stuck into the corresponding position of the car body.



5: The installation of the steering wheel, first connected to the steering wheel power socket, and then the excess line from the steering wheel edge hole plug into the car body, and then the steering wheel sleeve into the steering shaft can be fixed.









the seat back two buckle into the car body corresponding position, the seat plate into the lower backrest, with a screwdriver to tighten the first two screws can be.





Instructions



- 1. The manual rider sits down and switches on the power. Forward / stop / back switch set "forward", foot pedal switch, car forward, release the foot pedal, car stop. Forward / stop / back switch set "back", step on the foot switch, the car running backwards, release the foot switch, stop the car. The forward / Stop / back switch is in "stop" gear and the car can not run.
- 2. The remote control shows that code matching is required for the first time use. The product has built–in memory, no code matching is required for battery replacement.
- 1. Turn off the body power, hold down the "m" button of the remote control, do not release, 3 seconds after the first light began to blink, and then release the key.
- 2. At this point to open the body power switch, the remote control of the first light into the always bright state, the code success.
- 3. When the remote control is not in use 10 seconds will enter the hibernation state, press any key to wake up.
- 4. Key function description:" "forward," "backward," "left turn," "right turn,"s"speed,"p" brake, press"s"key to set speed, a light for low speed. Two lights for the medium-speed, three full light for high-speed, reversing only medium-speed press the "P" key into the braking state, all flashing lights, and then press the "P" key out of the braking state
- 3. In the non-cycling state, please turn off the power switch and turn off the forward / stop / back switch. Pressing the music button produces a different musical sound.

Instructions for remote control of mobile phone

- 1. We hat scans qr codes or searches the APP store for "little drivers" to download.
- 2. After downloading and installing, open the APP and open the Wireless connection on your phone.





Note: If mobile phone remote control is required, if you click on the "T mark in the upper left corner of the APP first, the remote control can not be operated. If you operate the remote control first, then the mobile phone remote control can not be operated. If you switch the device remote control again, you need to restart the baby car The APP currently supports most Android 6.0 IOS 8.0 and up.

Points to note


- 1. Not Be used in dangerous areas such as streets, roads, slopes, etc. .
- 2. Please drive on flat and good ground. Do not use it on smooth surfaces such as marble and tile.
- 3. This product is limited to one person, can not overload, the maximum load of 30KG.
- 4. The child must ride under adult supervision and the caretaker must not leave.
- 5. No alteration shall be made to the line of the vehicle or to the additional live equipment.
- 6. Do not use in water. Do Not pour water or other liquids onto the car.
- 7.Kill. The vehicle should not be blocked in the road to avoid damage to the device, if blocking phenomenon, please immediately release, foot switch, remove obstacles before cycling,
- 8. The bicycle should be timely charging when the speed is slow, riding too long will lead to a reduction in battery life.
- 9. When not in use, please turn off the power switch, long-term non-use, please unplug the battery connector.
- 10. It's not good to drive in the rain. Kill. The main use of PP materials, non-toxic, non-radioactive, safe use of the term of three years.

Description of packing unit

- 1 copy of product description
- One body
- 1 Saddle
- Remote Control 1
- 1 charger
- Kit 1

- Two Front wheels
- Two Rear wheels
- One steering wheel
- Four hubcaps

Sketch map of product



Maintenance

- 1. Parents should check whether the main parts are in good condition, battery, charger, wire, plug, jack and other parts are damaged before use. Whether the screw is loose or not, whether there is a hidden danger in the safety, should stop using when it is found to be damaged, until it is repaired in good condition.
- 2.Use a little bit of lubricating to lubricate the iron part of the vehicle for a period of time to prevent wear and rust.
 3.Vehicles should be placed away from the fire and avoid long-term illumination. Keep them flat and up-right. Do not lean down. In wet weather, the car should be parked indoors or covered with waterproof cloth.
- 4. Vehicles should be far away from the warmer objects, such as stoves and heaters, plastic parts may melt, charging, away from inflammable goods, to prevent fire.
- 5.Please charge in time after use. Charging must be operated by adults. If it is stored or not used for a long time, it must be charged first and then every three moths. To extend battery life.
- 6.Use dry soft cloth to wipe the vehicle, or use non-waxy furniture polishing material instead of soft cloth to wipe the plastic parts, so as to achieve the surface polishing effect, do not use chemical solvents to wipe the plastic parts of the vehicle, do not use soap and water to clean the vehicle, do not drive in rainy or snowy weather, water will damage the motor, the vehicle's circuit system and the vehicle. Battery.
- 7. When stopping using or placing the product, please cut off the power supply of the product and dial all switches to "stop" or "close" position.
- 8.Do not use fuse that is not in conformity with the crystal specification of this product.
- 9.Do not change the structure and circuit system of this product without authorization. The maintenance work must be professional or technical personnel. Conduct under guidance.
- 10.Do not use toys for other purposes.
- 11. Strictly prohibit battery short circuit.
- 12. Rechargeable batteries can only be charged under adult monitoring.
- 13. The battery is put in the right polarity.
- 14. The exhausted batteries should be removed from toys, and should be handled well to prevent children from playing.



RISK OF FIRE. Do not bypass. Replace only with 13A

Do not mix old and new batteries.

Do not mix alkaline, standard (carbon-zinc), or re-chargeable batteries.

Only use the battery specified by the manufacturer.

Only use the charger specified by the manufacturer.

The battery in the vehicle is not replaceable



To reduce the risk of injury,adult supervision is required. Never use in roadways,near motor vehicles,on or near steep inclines or steps,swimming pools or other bodies of water, always wear shoes,and never allow more than one rider.



The toy is to be assembled by an adult.